

From: christopher lee

Sent: Tuesday, November 25, 2014 8:21 PM

The question is this: when must a construction employer implement the High Hazard IIPP mentioned in T8 Section 1509? What are the criteria or threshold requirements? The language in 1509 states that "This model program has been prepared for use by employers in industries, which have been determined by Cal/OSHA to be high hazard. You are not required to use this program."